




# Dell Inspiron 14 M4010 Hard Drive Replacement

Written By: Terrence15



---

## INTRODUCTION


In this guide, we will be showing you how to remove and replace the Hard Drive.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Remove the Screws



**⚠ WARNING:** Before working inside your computer, read the safety information that shipped with your computer. Follow the instructions in [Before You Begin](#).


**⚠ WARNING:** If you remove the hard drive from the computer when the drive is hot, do not touch the metal housing of the hard drive.

**⚠ CAUTION:** To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface (such as a connector on your computer).

**⚠ CAUTION:** Hard drives are extremely fragile. Exercise care when handling the hard drive.


- Remove the two screws that secure the hard-drive assembly to the system board.

## Step 2 — Disconnecting the Hard-Drive Assembly



- Slide the hard-drive assembly to disconnect it from the connector on the system board.

## Step 3 — Lifting the Hard-Drive Assembly



- Lift the hard-drive assembly away from the system board.

## Step 4 — Remove the Screws




- Remove the four screws that secure the hard-drive bracket to the hard drive.

## Step 5 — Lifting the Hard-Drive Bracket




- Lift the hard-drive bracket off the hard drive.

## Step 6 — Align the Screws




- Align the screw holes on the hard-drive bracket with the screw holes on the **NEW** hard drive and replace the four screws.

## Step 7 — Connecting the Hard-Drive Assembly



- Slide and push the hard-drive assembly to connect it to connector on the system board.

## Step 8 — Replace the Screws



- Replace the two screws that secure the hard-drive assembly to the system board.