




# Razor A Handle Grips Replacement

Do your hands hurt or slip when riding your...

Written By: Jordyn



# INTRODUCTION

Do your hands hurt or slip when riding your scooter? Chances are your handle grips need to be replaced. This guide will show you how.

## TOOLS:


Container for water (1)


Scissors (1)

## PARTS:


Razor Scooter Handle Grips (1)

### Step 1 — Handle Grips



 If the scooter does not already have handle grips, skip to step 2.

- Locate the handle grips at the upper ends of the T-tube.

 Be careful to keep the scissors away from your other hand while cutting the handle grips.

- Wedge one end of a pair of scissors between the metal T-tube and a handle grip, with the cutting edge toward the handle grip. Cut the handle grip off.
- Repeat for the other handle grip.

## Step 2



- Soak the replacement handle grips in warm water for 2-3 minutes.
- ① The longer you soak the handle grips in water, the larger they get. Soaking the handle grips for a long time will not damage them.

### Step 3



- ⓘ Each handle grip should now slide onto the T-tube with ease. If not, soak the handle grip(s) in warm water for another 1-3 minutes.
- Holding the T-tube with one hand, slide a handle grip completely onto the T-tube.
  - Repeat for the other handle grip if installing both.
  - Let the handle grips dry for 24 hours before use.
-