




Droid Ultra XT1080 Battery Replacement

How to properly replace the battery in your Motorola Droid Ultra.

Written By: knoyes



INTRODUCTION

This guide is to replace a damaged battery on the Motorola Droid XT 1080. It is important because your phone will not charge or turn on if the battery needs to be replaced.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
 - [T5 Torx Screwdriver](#) (1)
 - [T4 Torx Screwdriver](#) (1)
-

Step 1 — Battery



- Remove the SIM card tray from the side of the device using a plastic opening tool.


Step 2



- After properly removing the SIM card tray take your spudger and press it in between the plastic case and the frame of the device until you hear a snap.
- Work your way from the top and the other side to confirm all the clips are disconnected.

⚠ Be gentle when performing this so you don't crack or break the plastic.

Step 3




- Remove the five screws on top of the device with a T5 Torx.
- Remove the single screw holding the camera with a T4 Torx.
- Remove the two screws on the bottom of the device with a T5 Torx.

Step 4




- After the top and bottom screws are removed remove the top and bottom plastic pieces that were secured to the device.

Step 5




- Begin to gently pry up the battery from the frame with a plastic opening tool to release it from its adhesive securing.

Step 6



- Remove the four T5 Torx screws securing the motherboard.


Step 7



- Gently pry the motherboard out of the frame using the nylon spudger.

⚠ Make sure not to damage the LCD cable in the process.

Step 8



- Disconnect the LCD cable with a spudger from the motherboard by gently lifting up the two connectors.

To reassemble your device, follow these instructions in reverse order.