



Nokia Lumia 2520 Display Assembly Replacement

This guide demonstrates the steps needed to replace the Nokia Lumia 2520 display assembly

Written By: Daniel Chevalier



INTRODUCTION

The Nokia Lumia 2520 is a tablet manufactured in 2013 and has a Microsoft based software. The tablet display has a 10 inch display size while producing a resolution of 1920x1080 pixels. If the screen on the Lumia 2520 is clean and not broken and the display on the tablet is pixelated or faded; the display assembly inside the tablet needs to be replaced.

This guide will demonstrate the steps needed to safely remove the display assembly for replacement.

TOOLS:

- [iFixit Pro Tech Toolkit](#) (1)
 - [Heat Pad](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
-

Step 1 — Display Assembly





- Apply heat pad to each side of the device.
- ⚠ When using any heat pad please use some form of padded gloves so you don't burn your fingers.
- ⓘ Microwave the pad for 30 seconds so an ample amount of heat is given on all four sides. Do not microwave more than once every two minutes.

Step 2






- Insert the pick between the glass to separate the glass from the device. You can also use the suction cups to help lift the glass.
- ⚠ When pulling the screen off the chassis, be careful not to cut the ribbon cable that connects the screen to the logic board.
- ✦ Take your time to pry open the screen from the chassis as you can easily break the screen or crack it.

Step 3



- Pull the ribbon cable out from the connection port on the board.
- Move on the step 4 to remove the ribbon connection from the screen.

Step 4



- Use the plastic pry tool to remove both of the connections.

Step 5



- Set aside the screen and the display assembly for repair.

To reassemble your device, follow these instructions in reverse order.