



Microsoft Surface Pro 6 Kickstand Replacement

This guide will show you how to replace the kickstand of your Microsoft Surface Pro 6 if it breaks or is damaged.

Written By: Sarah Westberg



INTRODUCTION

If you need to replace the kickstand of your Microsoft Surface Pro 6, this guide will show you how.

The kickstand is the part of the tablet that allows it to be propped up. If it breaks or is damaged, you might want to replace it. It's possible that your kickstand could become wobbly from overuse or if you drop it. The repair is not a difficult process, and you won't have to take apart the actual Surface Pro 6. You'll just have to remove and replace the kickstand itself.

TOOLS:


- [T3 Torx Screwdriver](#) (1)

Step 1 — Open the kickstand



- Lift the kickstand to expose the hinge screws.

Step 2 — Remove the kickstand screws



- Remove the four 2.7 mm T3 screws—two on each side of the kickstand.

Step 3 — Close the kickstand



- Move the kickstand back down to a flat position.
- ⓘ The hinges are stiff and you may need to use some force to get it down.

Step 4 — Remove the kickstand



- Remove the kickstand from the back cover.
- ⓘ There are two adhesive tabs in the middle of the kickstand that disengage most easily when the kickstand is pulled directly downward from the device.
- ☑ Be sure to insert these tabs when reinstalling the new kickstand before replacing the screws.

To reassemble your device, follow these instructions in reverse order.