



# Toshiba Satellite P755 S5390 Touchpad Repair

A broken touchpad is annoying on any laptop....

Written By: Dominic Oldani



# INTRODUCTION

A broken touchpad is annoying on any laptop. Sometimes this is an easy fix. Use this guide to fix a disconnected touchpad on your Toshiba Satellite P755 S5390.

## TOOLS:

Phillips #1 Screwdriver (1)

Spudger (1)

iFixit Opening Tool (1)


## Step 1 — Toshiba Satellite P755 S5390 Touchpad Repair



 Make sure that your laptop is powered off before starting.


- Close the cover and turn the laptop over so that the spine is facing away from you.

## Step 2



- Slide and hold the locks on both sides of the battery to the unlocked position.
- Slide and lift the battery out of its compartment.

## Step 3





- Use the Philips #1 screwdriver to remove the 15 screws from the base of the laptop.
- ☑ Keep track of these screws, you will need them in reassembly.

## Step 4



- Turn the laptop back over.
- Open the cover.

## Step 5



- Using either the iFixit opening tool or your hands, gently remove the keyboard from the base panel.


⚠ Do not touch the motherboard.

## Step 6



- Check if the touch pad cable is plugged into the ZIF connector on the motherboard.

## Step 7



- Grab the blue plastic above the touch pad wire.
- Firmly plug the cable into its socket on the motherboard.
- If you need information on how to remove or replace connectors take a look at the [Recognizing and Disconnecting Cable Connectors guide](#).

To reassemble your device, follow these instructions in reverse order.