



# PowerBook G4 Titanium Mercury Hard Drive Replacement

Written By: iRobot



---

## INTRODUCTION

How to remove the hard drive, along with its cable and bracket from your computer.

---

### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [T8 Torx Screwdriver](#) (1)
-

## Step 1 — Lower Case




- Turn the G4 over.
- Remove the eight Phillips screws from the lower case.

## Step 2



- Using your thumbs, slide the lower case away from you.
- ⓘ The lower case may stick in the front on a tab just above the center of the DVD drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.

### Step 3




- Your laptop should look approximately like this.

### Step 4 — Hard Drive



- Disconnect the hard drive ribbon from the logic board using a spudger or the tip of your finger.

## Step 5




- To free the hard drive, remove the two T8 Torx screws from the right wall of the battery housing.

## Step 6



- Remove the hard drive by gently grasping the orange ribbon cable and lifting the left edge up and out of the computer.
- ⓘ There are four rubber bumpers that fit over the hard drive screws. Ensure that these bumpers come out when you remove the hard drive.

## Step 7



- Your laptop should look approximately like this.

To reassemble your device, follow these instructions in reverse order.