



# Macintosh Powerbook 5300cs Keyboard Replacement

This repair guide shows how to insert and remove the keyboard on the Macintosh Powerbook 5300cs series, which was produced by Apple beginning in 1995.

Written By: Ronan



## INTRODUCTION

The [Macintosh Powerbook 5300cs](#) series was produced by Apple beginning in 1995.

Should you need to repair or replace the keyboard, this repair guide shows how to insert and remove the keyboard.

Repairing or replacing the keyboard will likely resolve any issues found with keyboard user input not registering on the machine.

There are no special skills required for this repair beyond familiarity with Apple products, including how to disconnect and reconnect the keyboard connector ribbon.

Tools needed include a Torx #9 screwdriver to remove the three .84 in. screws on the back of the laptop.

[Macintosh Powerbook 5300 Wikipedia image](#)



### TOOLS:

- [TR9 Torx Security Screwdriver](#) (1)
-

## Step 1 — Battery



- The battery compartment is located in the front-right side of the laptop.

## Step 2



- To insert the battery, gently slide it into the compartment until it clicks in place.
- To remove, slide the button highlighted in the red rectangle to the right to release the battery and slide it from the compartment.

## Step 3 — Keyboard




- With the laptop upside down and with the battery removed, use a Torx #9 screw driver to remove the three .84 in. screws shown.

## Step 4



- Carefully pull up on the front of the keyboard to pop it out from the case.
- Then slide the back out so the keyboard becomes nearly free.

## Step 5



- Disconnect the ribbon that is connecting the keyboard to the rest of the computer.
- Pull the keyboard out and repair or replace as needed.

To reassemble your device, follow these instructions in reverse order.