


Martian Victory LED Screen Replacement

Written By: Robert Sanchez



TOOLS:

1.5 mm Flathead Screwdriver (1) iFixit Opening Tool (1) Tweezers (1) Phillips #0 Screwdriver (1)

Step 1 — Back Plate






Unscrew the four 3.4 mm flat head screws




 Carefully lift the back plate off the watch. You will notice a lithium battery and rubber gasket attached to the back plate.

Step 3 — Lithium Battery




- i If not replacing lithium battery, skip down two steps.
- Using the plastic removal tool, pry the battery from the backing plate. The battery is simply attached with glue.



 Desolder the battery connections from the motherboard. Learn how to solder components <u>here!</u>

Step 5 — LED Screen




 Locate the ribbon connection, and use remove the clips holding the strip on each side using needle tool.




 With a pair of tweezers, carefully remove the ribbon strip connection.

Step 7



 Remove the screw driver holding the LED screen and Speaker in place.





 Insert a small flat screw driver under the speaker in order to remove it.

Step 9



Using tweezers, remove the speaker and move off to the side.





 Place a small flat head screwdriver under the LED screen, and carefully push it out of it's socket.

Step 11



 Remove final connection to accelerometer. The LED screen is now separated from the device.

To reassemble your device, follow these instructions in reverse order.