




Samsung Gear S2 Back Replacement

Has the watch become cracked or so scratched that the heart rate monitor on the watch does not work? Replace it using this guide.

Written By: Jacob Baldwin



INTRODUCTION

If the heart rate monitor on the watch no longer detects your heart rate, then replacing the back may fix it.



TOOLS:

- [Tri-point Y0 Screwdriver](#) (1)
 - [Heavy-Duty Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Watch Strap



- Flip the watch over so that the face is down.
- Using a Y#0 screwdriver, unscrew the four 3.5 millimeter tri-head screws.

⚠ Remember to turn off the watch to avoid being shocked.

Step 2




- Using your finger, push forward on the release while pulling up on the strap.
- ❗ You may find it helpful to use the flat end of a spudger to push on the release instead of your finger.

Step 3



- Repeat the procedure from step 2 for the other strap.

Step 4 — Back



- Insert a plastic opening tool between the top and bottom portions of the case, and gently pry off the back.

⚠ Do not insert the tool more than 3 millimeters into the case. Inserting more than 3 mm may damage the seal and electric components.

To reassemble your device, follow these instructions in reverse order.